

## Conversion Recommendations And Procedures

Change from CFC and HCFC to HFC refrigerants may cause a retraction in the o-rings and elastomers. Be sure to repair or replace after recovery of the original refrigerant. Failure to address this at this time may cause unnecessary loss of refrigerant.

ICOR recommends verification of the metering device sizing with the distributor or manufacturer of the device.

### 1) RECORD SYSTEM PRE-CONVERSION DATA:

Prior to converting, the system should be monitored and all system and component operating conditions recorded for future reference. (SEE FORM ON REVERSE SIDE)

### 2) RECOVER:

100% of the refrigerant must be recovered from system in accordance with all EPA guidelines. \*Recording the weight of the refrigerant you recover will assist you in determining the amount of Hot Shot 2 necessary for the conversion.

### 3) PERFORM OIL ANALYSIS:

Check system oil for acidity, water and solids (metal shavings). If detected perform a complete system oil change using the OEM specified type and amount of oil.

### 4) INSTALL NEW FILTER DRIER AND OIL FILTER:

The oil analysis will tell you what type of filter drier you need to use. Systems with coalescent oil separators and/or compressor oil filters need to be changed, too.

### 5) LEAK CHECK SYSTEM:

Pressure test system with dry nitrogen. DO NOT exceed the equipment's design pressure. Hot Shot 2 can be detected with any standard form of leak detection designed to detect HFC refrigerants.

### 6) EVACUATE SYSTEM:

To remove non-condensables and moisture in the system, a minimum 500 micron vacuum must be achieved.

### 7) CHARGE SYSTEM:

Remove LIQUID ONLY from Hot Shot 2 cylinder. When initially charging system, Hot Shot 2 can be added directly into the receiver tank or high-pressure side of the system with compressor off. Charge ratios for Hot Shot 2 may vary depending on system design and application. The initial charge of Hot Shot 2 should be 80% of the original R-12 charge.

### 8) RUN SYSTEM:

Check pressures, subcooling, and superheat temperatures. Use Hot Shot 2 P/T chart on reverse side. If additional Hot Shot 2 needs to be added, do so in 5% increments and DO NOT exceed 115% of the original charge of R-12. If system performance is inadequate, call ICOR for support at 800-497-6805.

### 9) PROPERLY LABEL SYSTEM:

Avoid mixing refrigerants by properly labeling your system. For Hot Shot 2 system ID labels, call the ICOR support hotline at 800-497-6805.

### 10) POST CONVERSION LEAK CHECK:

After operation of system begins, do a thorough system leak check.

### 11) RECORD SYSTEM POST CONVERSION DATA:

Monitor and evaluate system performance and record data. This information can be compared to your preconversion data for a full conversion evaluation and can be used if further technical support is required.

## REMEMBER WHEN CONVERTING OR RETROFITTING DID YOU.....?

- Adjust your low pressure control, evaporator or crankcase pressure regulator to the corresponding P/T relationship.
- Confirm the fan cycling setpoints. Unless the service conditions indicate contamination, oil change is not required and standard filter driers can be used. Remember oil loss can occur during the recovery process. Check oil level after system has stabilized. Adjust if necessary. If leaks occur, you may recharge (top-off) without effecting system performance. As with other replacements, systems directly converted from R-12 may experience shrinkage of o-rings or gaskets, which could contribute to leakage.

If there are any questions concerning the application of Hot Shot 2, contact ICOR INTERNATIONAL TECHNICAL SUPPORT AT 1-800-497-6805 OR [www.icorinternational.com](http://www.icorinternational.com).

Hot Shot 2 IS ANOTHER QUALITY PRODUCT FROM THE PRODUCERS OF HOT SHOT®, NU-22B® and ONE SHOT® LEADING THE INDUSTRY IN REPLACEMENT REFRIGERANTS

## CONVERSION GUIDELINES

# HOT SHOT2™

- EPA SNAP LISTED - STATIONARY EQUIPMENT ONLY
- NOT FOR USE IN MOBILE APPLICATIONS
- NON-OZONE DEPLETING
- COMPATIBLE WITH ALL STANDARD REFRIGERANT OILS
- LOWER CONVERSION COSTS
- R-12 LIKE OPERATING CHARACTERISTICS
- BROAD APPLICATION RANGE
- LOW • MEDIUM • HIGH TEMPERATURES
- BACKED BY WARRANTY

## TECH<sub>2</sub>TECH


REFRIGERANT RELATED  
DIAGNOSTIC SUPPORT  
866-433-TECH (8324)

## ICOR INTERNATIONAL

"making your life easier™"

ISO 9001:2008  
REGISTERED

10640 East 59th Street • Indianapolis, IN 46236  
Phone: 800-497-6805 • Fax: 317-826-3214  
E-mail: [icorinfo@icorinternational.com](mailto:icorinfo@icorinternational.com)  
[www.icorinternational.com](http://www.icorinternational.com)



# HOT SHOT<sup>2</sup>™

## CONVERSION GUIDELINES FOR R-12,134a and 500 DX SYSTEMS

Hot Shot 2 is a non-ozone depleting blend, which can be used as a direct refrigerant replacement into existing systems that are still operating on R-12, 134a and 500. It is compatible with all standard ACR system lubricants, i.e. MO, AB, and POE oils.

### SYSTEM REQUIREMENTS

- 1) System must be designed for use with R-12, 134a and 500 free of leaks, and in sound operating condition.
- 2) Hot Shot 2 is designed for use in systems utilizing direct expansion metering, i.e. TXV, orifice, cap tube. Before using Hot Shot 2 in a flooded system consult ICOR's technical staff. Hot Shot2 is not designed for use in mobile applications.
- 3) The system should be operating within its design capacity. Consult ICOR before converting any system with pre-existing capacity problems.
- 4) The system should be charged with the proper type and amount of lubricant, as required by the original equipment and component manufacturers.

### NOTIFICATION TO USERS:

The information contained in this document is given in good faith based on our current knowledge. It is only an indication and should not be construed as an endorsement or guarantee of performance to any specific application and is in no way binding. We guarantee that our products comply with our sales specifications. This information is not to be used as a substitution for system analysis as to suitability. Users are responsible for compliance with local, state, and federal regulations for recovery and evacuation.

EVAPORATOR					
Dew (F)	(psig)	Dew (F)	(psig)	Dew (F)	(psig)
-20	0.2	10	15.7	40	41.7
-18	0.9	12	17.1	42	43.9
-16	1.8	14	18.5	44	46.2
-14	2.6	16	20.0	46	48.5
-12	3.5	18	21.5	48	50.9
-10	4.4	20	23.0	50	53.3
-8	5.4	22	24.7	52	55.9
-6	6.3	24	26.3	54	58.5
-4	7.4	26	28.1	56	61.1
-2	8.4	28	29.8	58	63.9
0	9.6	30	31.7	60	66.7
2	10.7	32	33.6		
4	11.9	34	35.5		
6	13.1	36	37.5		
8	14.4	38	39.6		

CONDENSER					
Bubble (F)	(psig)	Bubble (F)	(psig)	Bubble (F)	(psig)
80	107	102	155	122	209
82	111	104	160	124	215
84	115	106	165	126	221
86	119	108	170	128	227
88	123	110	175	130	234
90	127	112	180	132	240
92	132	114	186	134	247
94	136	116	191	136	254
96	141	118	197	138	261
98	145	120	203	140	268
100	150				

Conversion Data:	PRE	POST
Suction PSIG	_____	_____
Suction Temp	_____	_____
Discharge PSIG	_____	_____
Discharge Temp	_____	_____
Evap. Superheat	_____	_____
Comp. Superheat	_____	_____
Subcooling	_____	_____
Ambient Temp	_____	_____
Weight of Refrigerant	_____	_____
Comp. Oil Temp	_____	_____
Comp. Oil Level	_____	_____
Comp. Motor Amps	_____	_____
L1 _____	L2 _____	L3 _____